

Meas.Nr. 71746 **Date** Tuesday, 07 January 2014 08:18 AM **Personal Report No.:**
Material Porcelain 90 min P5cl 500ml 1mm ZrO2 **M130348**
Description predisp in 0,1% Na4P2O7 1 min ultrasonic bath LABORETTE 17

Calculation Fraunhofer broad **TradeOff** 1.000000e+002
Scans Fine 100 **Scans Coarse** 0 **Channels** 51 **Beam Obscuration** 15.00 %
Meas. Range 0.08 [µm] - 42.30 [µm] **Pump** 5 **Ultrasonics** 10

%	< µm
5	0.37
10	0.50
15	0.58
20	0.65
25	0.71
30	0.78
40	0.90
50	1.03
60	1.18
70	1.35
80	1.59
90	1.97
95	2.38
98	3.13
99	16.48

%	< µm
1.5	0.10
3.6	0.20
9.9	0.50
16.4	0.60
32.0	0.80
47.7	1.00
61.5	1.20
76.6	1.50
86.2	1.80
90.4	2.00
96.0	2.50
97.8	3.00
98.3	3.50
98.4	4.00
98.4	5.00

